

Interpreting CON29DW Water Asset Plans

Wessex Searches are the official producer and only source of the Law Society's CON29DW Residential and Commercial in the Wessex Water region. We believe in producing high quality searches with the customer in mind, ensuring that they feel confident and informed about the property they are purchasing. We guarantee to leave no questions unanswered.


There are 4 key features with our asset plans contained within the reports:



You will always receive two separate plans for clarity; one drainage and one foul, locating the publicly maintained assets, all referenced from water company records for accuracy.




All maps are orientated north.



Arrows are always on pipework to indicate the direction of flow.



All known public apparatus will be indicated with the corresponding legend for easy referencing.






















 All your searches from the source you trust

If you would like to find out more about Wessex Searches and what we can offer you and your clients, get in touch today to start a conversation with us!

t: 01225 526206
e: contactus@wessexsearches.co.uk
w: www.wessexsearches.co.uk



Asset	Asset name	Description
	Distribution Main	A distribution main carries treated water to customers. With few exceptions, domestic water connections are only made to distribution mains.
	Raw Water Main	A raw water main carries untreated (raw) water to a Water Treatment Works.
	Washout Main	A main used for maintenance and management of the water supply network, to flush out or empty connected assets.
	Abandoned Main	Abandoned mains are not in use but may still be in the ground.
	Private Main	Mains not in the use of Wessex Water but are recorded to assist work in the geographical vicinity. Wessex Water does not know ownership.
	Open Valve	Open sluice valve used to regulate the flow of water.
	Closed Valve	Closed sluice valve used to regulate the flow of water.
	Closed Valve (DMA)	Closed sluice valve that denotes the boundary of a metered area.
	Closed Valve (Black Cap)	Permanently closed sluice valve.

Asset	Asset name	Description
	Washout Valve	Valve that is occasionally used to clear out sediment or drain-down part of the network.
	Fire Hydrant	
	Washout Hydrant	Hydrant that is occasionally used to clear out sediment or drain-down part of the network.
	Air Valve	Valve used to remove (bleed) air from the mains network.
	PRV (Pressure reducing valve)	Valve used to control or limit the pressure in the mains network.
	PSV (Pressure sustaining valve)	Valve used to maintain a set pressure at a specific point in the mains network.
	NRV (Non-return valve)	Valve that allows water to flow in only one direction.
	End Cap	Fitting used to terminate (cap-off) a main.
	Network Meter	Meter used to internally manage/monitor the mains network.
	Booster Pump	Pump used to maintain pressure in the mains network.